

1. Identification/recognition			
			t identification Humber
2. Immobilisation/stabilization/lifting			
1 2 1. Points of lifting 2. Ventilation 3. Lifting points for for 4. Stackable constru	ction		
3. Disable direct hazardous/safety regulation	ons		
 1 Turn off the power switch (1) to the off position. 2 Open the service flap. 			
3 Turn the battery disconnect switch (2) to the off	position.		
 If the machine is charging and connected with a stand Disconnect the connector from the charging source Press the button (1) (charging initiating button) to charging procedure. Disconnect the connector from the machine. 	rce, if possible.	ector	
 If the machine is charging and connected with a fast charging connector Press the button (1) on charger or PU to interrupt charging (if in danger this go directly to point 2). 			
2 Open the hatch.3 Disconnect connector from PU.			
	Identification number	Version number	Page number
	54116502	01/2024	2

